

Refer to the CertainTeed Shingle Applicator Manual for underlayment and shingle application guidance.

## CertainTeed Flintlastic Strip

Fully adhere (self-adhered, cold process). **If self-adhered** apply Flintbond® Caulk at edge; **if using cold process** set in FlintBond Trowel with 1/4" bleed out at edge.

## **Anchor Sheet, Field**


Mechanically attach with cap nails or approved fasteners spaced a minimum 9" o.c. in sidelaps and two staggered rows space 18" o.c. in the field.

## **Edge Metal**

Set in FlintBond Trowel. Mechanically attach a minimum two staggered rows, 6" o.c. or as required by building code; endlaps should receive two nails. <u>Prime surface with FlintPrime® Aerosol.</u>

## **Cap Sheet**

Fully adhere (self-adhered, torch, cold process or hot asphalt). Proper attachment is defined by product selection. **If self-adhered,** in cold weather<sup>1</sup> hot air weld<sup>2</sup> with bead of FlintBond Caulk at edge.



<sup>1</sup>20°F-49°F (-6.6°C-4.4°C)

<sup>&</sup>lt;sup>2</sup>Apply heat from a hot-air welder with a 2" tip to the metal surface while applying rolling pressure from a silicone roller to the overlapping Cap. With the hot air welder set between 300°F-500°F (setting 2-3), apply heat to the overlap interface while bonding Cap with rolling pressure onto the Metal. Roll the overlapping Cap in place, moving the hot air welder to allow for forward progress. Avoid applying so much heat or moving at a pace that results in smoke.