

Anchor Sheet or Base Ply, Field

Mechanically attach or fully adhere (self-adhered, torch, cold process or hot asphalt). Proper attachment of the base layer is defined by specified system, product selection and deck type.

Cap Sheet, Field

Fully adhere (self-adhered, torch, cold process or hot asphalt). Proper attachment is defined by product selection.

Cap Sheet Flashing Strip

Treat the granulated surface of Cap Sheet, Field, where the Flashing Strip overlap occurs: **If self-adhered or using cold process** apply FlintBond® Trowel to entire lapped surface with 1/4" bleed out or (in cold weather¹) hot air weld² with


bead of FlintBond Caulk at edge; **If torch-welded (cap only²)** heat sink/scrape the granules with heated trowel or granular embedment tool and ensure 1/4" bleed out; **if using hot asphalt** apply to entire lapped surface with 1/4" bleed out.

Weatherproofing Strip

Self-adhere WinterGuard® Metal, WinterGuard® HT or Flintlastic® PlyBase/MidPly and mechanically attach top edge according to building code.

Edge Metal

Mechanically attach as required by building code; space fasteners so as not to overlap weatherproofing fasteners.



NOT DRAWN TO SCALE

¹20°F-49°F (-6.6°C-4.4°C)

²Apply heat from a hot-air welder with a 2" tip to the overlapped granular surface while applying rolling pressure from a silicone roller to the overlapping Cap. With the hot air welder set between 900°F-1,100°F (setting 8-10), apply heat to the overlap interface while bonding Cap with rolling pressure on the granulated surface. Roll the overlapping Cap in place, moving the hot air welder to allow for forward progress. Avoid applying so much heat or moving at a pace that results in smoke. Apply a bead of FlintBond Caulk along the edge. Continue overlap application, 2" per pass.